



**Legend**

**Valve**

**SubtypeCD**

Block

Check

**Pipe**

**REMARKS**

NPS 10 Dorval Lateral

NPS 10 Montreal Feeder - Shell to Ultramar

NPS 10 Montreal Feeder - Ultramar to Montreal Station

NPS 10 Montreal Jet Line - Montreal Station to Ste Rose Junction

NPS 16 Montreal Line - Montreal Station to Ste Rose Junction

NPS 10 Montreal Line - Ste Rose Junction to Ste Marthe Transition

**Facility Location selection**

**Name**

Dorval Meter Station

Montreal Pump and Meter Station

Saint Rose Junction

